



INSTALL PTFE TAPE ON ALL NPT THREADS.

- A) WHITE TAPE FOR LESS THAN 1" THREADS.
- B) PINK TAPE FOR 1" THREADS AND UP.
- C) GRAY TAPE FOR STAINLESS STEEL THREADS.



The Right Connection™

dixonvalve.com

<p>PROPRIETARY AND CONFIDENTIAL</p> <p>This drawing is owned by Dixon Valve & Coupling Co. and shall be returned upon demand. It is loaned on condition that it shall not be copied or reproduced or submitted to others without the owners consent. In accepting it subject to this condition the recipient further agrees that this drawing or any design detail or concept disclosed herein shall not be used in any way detrimental to or in competition with the owner. If the recipient does not agree to the terms of this agreement they shall return this drawing immediately. The information contained in this drawing is subject to change without notice.</p>	<p>DIXON U.S.A.</p> <p><i>THE RIGHT CONNECTION™</i></p>
	<p>TITLE: RAILCAR UNLOADING ADAPTER</p>
<p>DO NOT SCALE THIS DRAWING</p>	<p>MATERIAL: -</p>
	<p>PART NUMBER: TF080000N00DB12</p>